

SURFACE APPLIED INSTALLATION




Place the tile on the designated location and trace the perimeter with a thin permanent marker.



Set the tile aside and using a 100mm diamond cup grinder, scour the concrete within the marked location and in correspondence with the location requiring adhesive as indicated in backside of tile.



Clear away the dust with a leaf blower then clean the back of the tile and the concrete with rag soaked in acetone.




Apply adhesive to back of tile (as indicated on tile). The first bead should be applied thin, 12mm from the perimeter edge and a second thicker bead applied 25mm inside of the first.



Set the tile true and square to the curb ramp and press down firmly.



While stepping down on either side of pre-formed hole, drill down 75mm into concrete slab using a hammer drill and the recommended 6.5mm diameter carbide drill bit.




While still applying pressure, remove the dust and any adhesive that surfaces and carefully set the supplied color-matched fastener with a hammer. *Repeat* steps 6 & 7 while working across the tile from one end until all pre-formed fastener locations are completed.



Clean the perimeter of the tile and the immediately surrounding concrete with acetone making sure to remove any adhesive that has escaped from beneath the tile.




Mask the edge of the tile and the concrete leaving a 12mm gap back from the tile's perimeter edge.



Apply the perimeter sealant.



Using a plastic applicator or spatula smooth out the sealant in a cove profile between the tile and adjacent concrete.



Carefully remove the masking tape immediately after tooling the perimeter sealant.